
Meridian 1

Meridian Companion

Installation and Maintenance Guide

553-3601-220

Issue 03

July 1997

© 1997 Northern Telecom
All rights reserved

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant.

Meridian and Companion are trademarks of Northern Telecom.
Windows is a registered trademark of Microsoft in the U.S.
Printed in the United States of America

Contents

Introduction to Meridian Companion1

Preparing to install a Meridian Companion system	1
Installing a Meridian Companion system	2
Installation warnings	3
Safety precautions	6
System overview.....	10

Installing the hardware.....11

Installing Base Stations.....	12
Installation guidelines	12
Powering a Base Station.....	13
Mounting a Base Station.....	13
Installing remote power interconnect units.....	16
Mounting the remote power interconnect unit.....	23
Wiring the remote power interconnect unit	25
Upgrading an RPI-8 to an RPI-16	29
Mounting a Base Station plug-top power supply.....	30
Installing external antennas and lightning surge arrestors.....	34
Installing an indoor directional external antenna.....	35
Installing an indoor omnidirectional external antenna.....	36
Installing an outdoor omnidirectional external antenna.....	38
Installing the lightning surge arrestor	40

Installing a Companion Administration Terminal.....	41
Installing the Administration Terminal	41
Mounting the Administration Terminal on a wall	42
Installing Companion Manager.....	42
Installing the PC Interface Card	42
Setting the base address dip switches	43
Installing the PCI card	45
Setting the hardware interrupt.....	45
Installing a Remote Access Device	46
Remote Access Device configuration options	47
Wiring the Time Compression Multiplexing lines	50
Planning the IPE and CE/PE module wiring.....	50
Installing Meridian Companion cards	58
Normal LED behavior upon installation.....	59
Placing cards.....	61
Installing cards	65
System initialization.....	69
Verifying initialization	69
Are arrow indicators flashing?	69
Do you see Select country?	69
Did you install more Base Stations?.....	70
Do you see Re-Eval required ?	70
Memory Reset.....	71
Programming the Meridian Companion system.....	73
The Meridian Companion Programming and Provisioning Record.....	74
The Administration Terminal	74
Buttons	74
Operating the Administration Terminal	76
Adjusting the contrast.....	76
Entering a Configuration programming session	76

Entering an Administration session	76
Ending a programming session	77
Recording and reporting alarm messages.....	77
Choosing set languages for a custom setting	78
Verifying card status	78
Verifying Base Station status	79
Programming telephony data.....	80
Delay to Dial	80
B03 gain value modification.....	81
Portable telephone side tone	82
CMCC slot	82
Dual tone multifrequency timing	83
Pulse code modulation mode	84
Programming mobility data	85
Setting the antenna type for a radio.....	85
Setting the System Access Logical Identifier.....	86
Programming the system time and date	88
Programming the system time	89
Programming the system date	89
Changing passwords	90
Changing the Installer password	90
Changing the Administration password	92
Changing the Registration password	93
Activating wireless communications	95
Activating a new system	95
Verifying the Meridian Companion installation	97
Viewing radio and cell assignments.....	98
Identifying a radio's cell assignment	99
Configuring the Meridian 1 for the Meridian Companion system.....	101

X11 release 15 or greater without package 240.....	103
X11 release 20B or greater with package 240	104
Wireless telephone privacy	105
Programming options	105
Programming user options	109
Programming Call Transfer on Radio Loss	109
Programming a system default for radio loss handling	110
Programming individual Call Transfer on Radio Loss	110
Registering and verifying portable telephones	113
Enabling and disabling registration.....	113
Registering portable telephones	114
Verifying a portable telephone's operation	114
Verifying that a portable can make or receive calls	114
Optional checks	115
Deregistering the wireless terminal number	115
Maintenance.....	117
Using maintenance commands	117
Meridian 1 card maintenance.....	118
Administration Terminal maintenance commands	118
Maintenance features	119
System status.....	120
Card status	122
Wireless terminal number status	124
Time compression multiplexing status.....	126
Event/Alarm log	128
Entering the Event/Alarm log.....	129
Administration log	130
Entering the Administration log	131

Responding to event and alarm messages	132
Responding to an alarm code.....	132
System Reevaluation	133
Scheduling System Reevaluation	137
Replacing equipment	139
Adding or moving Base Stations.....	139
Replacing a defective Base Station	141
Adding expansion cards	141
Relocating the system	143
Replacing a defective expansion card	146
Replacing a defective ROM card	147
Replacing a defective CMCC.....	149
Replacing a defective remote power interconnect unit	149
Replacing a defective remote access device	151
Replacing a defective Administration Terminal	151
Replacing a portable.....	151
Handling Meridian Companion exceptions	151
Config warning: Recoverable inconsistency	152
Config failure: Nonrecoverable inconsistency	152
Troubleshooting	153
General troubleshooting procedures	153
Troubleshooting power problems	155
Troubleshooting cards.....	155
Normal card LED behavior	156
Troubleshooting the Administration Terminal	158
Troubleshooting a Base Station	159
Troubleshooting a remote power interconnect unit	160
Troubleshooting portable telephones	161
Troubleshooting a remote access device.....	163

Troubleshooting an alarm	163
Understanding event messages	167
Appendix A: Programming overview	171
Appendix B: Regulatory information	173
Registration	173
Safety	173
Equipment attachment limitations	173
Telecom Compliance	174
Telephone Company Notification.....	174
Rights of the Telephone Company	175
Interference causing equipment	175
Load Number.....	175
Repair facility	176
General installation warnings	176
List of terms	179
Index	187